

<Power/Power Saving> Button

(Power On/Off or Enter/Exit Power Saver)

<Home> Button

(Press to display Home screen)


<NFC Touch Area>

(Hold NFC device over this area)




<Data Indicator>

(Indicates when data or faxes are stored)




### COPY

1. Tap on Copy on the Home Screen
2. Configure the required features
3. Set the Quantity
4. Tap on Start



### FAXING

1. Tap on Fax on the Home screen
2. To enter the fax number, tap on Add Recipient
3. Dial 0 first if required, then enter the fax number
4. Tap on Done
5. Tap on the Features List and configure the required features
6. Tap on Start



### SCANNING

1. Tap on Scan on the Home Screen
2. Select the scan method or tap on Select from Address Book.
3. Select the required address, then tap on OK
4. Tap on the Features List and configure the required features
5. Tap on Start



More online resources are available for your product

1. Apple iOS users: Read QR code with the mobile's camera (Note: Android use chrome web browser).
2. Other mobile users: Download a QR Code Reader Application onto your mobile device, then open the app.
3. Hold device camera over the QR.
4. The FUJIFILM Business Innovation Support Centre will open.

Access self help, drivers, documentation, videos & more:

- a. Enter your product name or number into the search box
- b. Select your product name from the list of suggestions.
- c. Choose the type of support that you require.

support-fb.fujifilm.com